

## **Operating Instructions: Chelsea Cantilever Umbrella**



To open canopy: Lift canopy lever

To raise and lower canopy: Squeeze canopy handle to engage and position in desired location on pole; release handle

To turn canopy to left or right (swivel): Step on swivel knob on base while grasping canopy handle; turn canopy into desired position and release handle and pressure on swivel knob

To level base, or to engage wheels to move umbrella, use wheel key supplied and turn corner wheel buttons to lower wheels; position umbrella as desired